

ELITE TABLE TENNIS TABLE



ALL TABLE SPORTS

ASSEMBLY INSTRUCTIONS



All Table Sports Australia

Add: Unit 2-5/20-26 Sullivan St,
Moorabbin, Victoria, 3189
Ph: 03-9553 1418

Email: info@alltablesports.com.au
Web: www.alltablesports.com.au




Indoor use only

OPEN


1st

UNLOCK



2nd

STRAIGHTEN



PLEASE NOTE:
The folding & unfolding should be carried out by adults only.


Do not get the table wet or use a wet cloth to clean the table. Please refer to the user manual for cleaning instructions.

CAUTION:
Follow the instructions carefully when handling the table.

CLOSE


1st

COLLAPSE



2nd

LOCK



IMPORTANT



DO NOT LEAVE CHILDREN UNATTENDED AROUND THE TABLE.

IMPORTANT



DO NOT SIT OR STAND ON THE TABLE, BECAUSE OF THE RISK OF COLLAPSE.

IMPORTANT



BE VERY CAREFUL WHEN MOVING THE TABLE ON A SLOPED SURFACE.

IMPORTANT



TABLE MUST BE KEPT AND USED IN AN INSULATED BUILDING.

The Guarantee does not cover any damage which occurs as a result of incorrect use.

Warranty

The Elite Table Tennis Table has 12-month warranty for its components starting from the acquisition date. Warranty covers manufacturing defects only.

Warranty does not cover:

- Normal wear and tear
- Damage arising from abnormal use, neglect, abuse, or incorrect installation by the purchaser or third party
- Damage resulting from flood, fire, earthquake or other natural disasters
- Products which have not been maintained or which have been modified
- Insignificant minor variations in dimensions, colour, finish, and very minor chips or superficial blemishes
- Non-commercial tables used in commercial, rental trade, institutional or other non-residential use
- Warranty will end immediately if the games table becomes defective as a consequence of misuse, lack of proper care and maintenance, used in an improper environment or handling in transit

Table Features Key Point:

- All connection points fixed by lock nuts resisting loosening.
- 19mm Medium Density Fiberboard (MDF).
- Playback function.
- Multi-layered paint finish with UV protection.
- 40MM powder coated square metal legs & frames.
- Safety Locking Mechanism.
- Hard plastic corner capping protectors.
- 8X3"(75MM) diam. lockable wheels.
- 4 adjusting rubber feet.




ALL TABLE SPORTS ELITE TABLE TENNIS TABLES INSTRUCTION

Assembly Instructions

Unlock and unfold the pre assembled frame underneath the table top. Lock the legs into position ensuring the leg hinge(A) is straight. Then slide the 'T' leg (B) (The “T” bar with the wheels on the base) into the designated position and ensure the designated markings(C) line up on each side, see figure 1.

Figure 1



Preparation for use


1. Open the carton and check to ensure all accessories and fittings are complete.
2. Install 'T' rolling leg according to figure 1 above.(B)&(C)
3. Tighten all screws and turn table up right ready for use.

Care and Maintenance for use of your Table

1. Two pieces of table top have to be separated before folding or opening.
2. Do not place table outside for playing.
3. Do not beat on surface of table with bat.
4. Do not place hot goods on table top.
5. Do not place heavy goods on table to avoid distortion, this includes sitting on table.
6. Do not use table for any other exercise other than table tennis.
7. Do not move table around quickly on rough or uneven surfaces.
8. Keep table in dry well, ventilated place to avoid exposure to sun and rain.

Operation Method

Security Lock Operation



Release the lock (A) before opening the Table Tennis Table and lock it when folding the table.

Leg Hinge


Straighten when in use Collapsing when folding table for storage



Straighten hinge when using table and collapse hinge to fold table.

Wheel Operation

Locked Unlocked



Lock wheel tightly when using table or storing, and unlock for moving around.

Height Adjusting Method

Wheel





Figure 5

The wheel height can be adjusted to a maximum of 15mm.

Foot



The foot height can also be adjusted to a maximum of 15mm.

To adjust the table height at wheel, screw part A (as seen in figure 5) anti-clockwise to raise table, and Part B clockwise to lower table.

To adjust table height at the foot, screw foot anti-clockwise to rise, and clockwise to lower.

All feet can be adjusted slightly to ensure a level playing surface.